



ARMORY

**OWNER'S MANUAL**  
**BUL CHEROKEE**



**IMPORTANT SAFETY INFORMATION :**

**Read and UNDERSTAND this manual BEFORE using this firearm.**

**If you lend, give or sell this pistol make sure the manual is included with it.**

This manual contains important warning, which should be read and understood before using this firearm.

**SAFE GUN HANDLING IS YOUR PERSONAL RESPONSIBILITY AT ALL TIMES.**

Disregarding warnings in this manual may result in injury or death to you and others and damage to property.

Directions and procedures for handling, loading, firing and unloading.

Instructions for care, cleaning, repair and service of this pistol.

This instruction and safety manual is designed to help you in learning how to properly use and care for your BUL Cherokee. Only when you are certain you have fully familiarized yourself with the function of your firearm should you practice loading, unloading and firing with live rounds of ammunition.

This instruction manual should always accompany this firearm, and be transferred with it upon change of ownership. Should you ever need to replace it, this manual is available FREE upon request from BUL ARMORY.

**WARNING!!!** Prior to removing this gun from its packaging, and prior to loading and firing, carefully and thoroughly read the entire instruction manual which gives advice on the gun's proper handling and functioning. However, your safety and that of others (including your family) depends on your responsible compliance with that advice. If unfamiliar with firearms, seek supervised instruction.

# PISTOL NOMENCLATURE



- |                  |                     |
|------------------|---------------------|
| 1. Slide         | 7. Trigger          |
| 2. Front Sight   | 8. Magazine Release |
| 3. Rear Sight    | 9. Magazine         |
| 4. Hammer        | 10. Grip safety     |
| 5. Thumb Safety  | 11. Slide stop      |
| 6. Trigger Guard | 12. Accessory rail  |

## SPECIFICATION BUL CHEROKEE

	<b>Cherokee compact</b>	<b>Cherokee Full size</b>
<b>Caliber</b>	9mm	9mm
<b>Barrel</b>	3.66"	4.45"
<b>Slide</b>	Steel Forged	Steel Forged
<b>Type of action</b>	DA/SA	DA/SA
<b>Frame</b>	Injected Fiber reinforced polymer	Injected Fiber reinforced polymer
<b>Frame type</b>	Polymer	Polymer
<b>Finish</b>	Black oxide	Black oxide
<b>Supplied magazines</b>	2	2
<b>Capacity</b>	17	17
<b>Safety</b>	Manual, Firing Pin safety	Manual, Firing Pin safety
<b>Sights</b>	3 Dot	3 Dot
<b>Weight</b>	730g	797g

## SAFETY



OFF SAFE



ON SAFE

**OFF SAFE:** The safety is "off safe" when you can see the red dot and the lever is pointed forward.

**ON SAFE:** To put the pistol in the safe position, push the safety lever up so that it covers the red dot.

The safety can be operated with the hammer cocked or de-cocked and with the pistol loaded or unloaded.

There is no magazine safety, so the pistol may be fired with the magazine removed.

All guns can be dangerous if improperly used. Keep your pistol "on safe" at all times, except at the actual moment of firing. This will help to prevent accidental firing and possible injury or death to yourself or others.

## **GENERAL SAFETY WARNINGS:**

1. Careless and improper handling of this gun could result in unintended discharge causing injury, death or property damage. Safety must be the first and constant consideration when handling a firearm and ammunition.
2. This pistol was designed to function properly in its original condition. Alterations can make it unsafe. DO NOT alter any parts or add or replace parts on your own. Always let only a qualified gunsmith work on your pistol. Assembling the pistol incorrectly or with modified incompatible parts can result in a dysfunctional pistol, that may put you and others in danger of injury or death.
3. Pistols should only be carried with the magazine and chamber empty to prevent accidental discharge.
4. Always handle and treat your gun as if it were loaded at all times, so you never fire it accidentally when you think it is unloaded. Never take anyone's word it is unloaded. Always check it yourself with your fingers off the trigger and the gun pointed in a safe direction.
5. Never keep or carry any pistol with the hammer cocked. Cocking the hammer or pulling the trigger should only be done when you are ready to shoot immediately. This way, your gun cannot be unintentionally fired. Your pistol cannot normally fire unless the trigger is pulled. Never place your finger inside the trigger guard unless you intend to fire.
6. Water, snow, mud, excessive lubricating oil or grease or any other material can obstruct the barrel of your gun. Always check the barrel of your firearm for obstruction before loading and firing. Clean a fouled gun immediately to ensure its correct and safe function.
7. Keep the gun's muzzle pointed in a safe direction at all times. Never let the muzzle of a firearm point at any part of your body, another person or at anything you do not intend to shoot. Always be certain of your target before firing.
8. UNLOAD ALL FIREARMS WHEN NOT IN USE. NEVER STORE A LOADED FIREARM. Firearms and ammunition should be safely stored separately so that they are inaccessible to children or unauthorized users.
9. Never rely on a gun's "safety" to protect you from accidents. A safety lever is only a mechanical device - it is not a substitute for common sense.

10. Never leave your gun unattended.
11. Always make sure your gun is not loaded before cleaning, storing or handing it to another person.
12. Always wear safety glasses while shooting to protect your eyes from injury by gun powder, gas, lubricant, dirt or metallic particles, carbon residue, sparks or other debris.
13. Always wear ear protection when shooting, especially on a range. Without ear protection, the noise from your gun and other guns close to you could leave a "ringing" in the ears for some time after firing. Repeated exposure to shooting noise could result in permanent hearing loss.
14. Never carry a pistol in your pocket, purse or tucked in your belt. Use a pistol case or a proper holster with a safety flap or strap.
15. Never climb a tree, fence or wall while carrying a loaded firearm.
16. Do not shoot at a hard surface, or at water. A ricochet may travel in unpredictable directions to strike you or an object you cannot see.
17. Be sure of your target and what is behind it before you shoot. Always ask yourself "What will I hit if I miss my target?"
18. Firearms and alcohol do not mix. Never drink alcoholic beverages or take drugs before or during shooting, as this constitutes criminal disregard for your safety and that of others. Never use a gun while you are taking medication unless you have checked with your doctor to ensure your fitness to handle your gun safely.
19. After removing the magazine from your pistol, check to be certain a live round does not remain in the chamber.
20. If you have any doubts about your ability to handle or use this pistol safely, seek supervised instruction.
21. Horseplay has no place around firearms. Guns can not think - YOU CAN!
22. Remember: Safety is YOUR responsibility! Be a safe shooter!
23. FOLLOW THE LAW: Obey all local, state and federal laws regarding storage, shooting and transporting your firearms.

## **FIRING**

**WARNING!!!** Read and understand all instructions and warnings in this manual BEFORE using the pistol!

It is important to learn the parts of your BUL Cherokee and their functions before using this firearm.

**WARNING!!!** Remember, if you have already drawn back the slide over a loaded magazine, there is now a live cartridge in the chamber. Make sure your safety is in the "safe" position until you are ready to fire. Be sure of your target and what is beyond before firing.

1. To fire the pistol, hold your BUL Cherokee in a natural shooting position and return the thumb safety to the "off" position by lowering the safety to a parallel position with the slide.

The safeties are now off and the pistol will fire when the trigger is pulled.

2. After the round is discharged, the slide will travel rearward, allowing the spent case to be ejected and replaced with a live round.

3. This process can be repeated until the magazine has been emptied at which time the slide will lock open.

**WARNING!!!** Be sure to hold the pistol by the grip and keep both hands well clear of the slide operation and away from the muzzle. Be sure to wear eye and hearing protection when firing.

**WARNING!!!** Should a cartridge fail to fire when the trigger is pulled, keep the pistol pointed in a safe direction, remove your finger from the trigger and wait 30 seconds. You may then unload the pistol and dispose of the cartridge properly. If you hear an unusual sound on firing, stop firing, unload and check the barrel for obstructions.

# BUL ARMORY LIMITED 1 YEAR WARRANTY AGREEMENT

Bul Armory proudly manufacture specialized custom made handguns for many years.

Our guns are built to the highest standards with a strict quality control process to ensure that our product will leave our factory at the highest quality and craftsmanship. Bul Armory will service any defect in material or functioning of the pistol for full 1 year from the date of purchasing by original owner caused under normal use.

Bul Armory will repair or replace defective parts according to its own discretion after evaluating each claim.

Responsibility and expenses for shipping and handling of the pistol to our service center and back to the customer will be applied on the customer only. Warranty for coating will be valid for 6 months for original owner only for defects, excluding damages or wear and tear or abuse.

Warranty will not be valid on the following cases:

- Improper use or abuse of the pistol or its parts.
- Improper use of ammunition (use of improper ammunition or reloaded ammunition or hand loaded ammunition will void the warranty).
- Lack of maintenance or negligence of the pistol.
- Any change of parts of the pistol (including cosmetics) or service made by other than BUL ARMORY authorized gunsmith.
- Damage caused by normally wear and tear.
- The use of non-original factory magazine.

Bul Armory will not be held responsible for any damage or expenses direct or in-direct accrued due to this warranty.

Bul Armory will not be responsible for any damage or malfunction to any accessory or item attached to the pistol or related to it. Bul Armory reserve its right to charge for any repair not covered by this warranty.

This warranty is not transferable to any other person but the original buyer.

**Please feel free to contact us anytime for additional information and inquires**

**USA contact: [usa@bularmory.com](mailto:usa@bularmory.com)**

**Worldwide contact: [yonel@bularmory.com](mailto:yonel@bularmory.com)**

## **IMPORTANT!**

Your firearm is supplied with this manual by the manufacturer. Insist on receiving the manual from your dealer if the manual is not submitted with the pistol. Read and understand the manual, including the special warnings and precautions before removing this firearm from its package.

## **KEEP THIS CARD FOR YOUR RECORD**

Any claim made under this limited warranty must be accompanied by this card.

Name of Owner: \_\_\_\_\_

Address: \_\_\_\_\_

Pistol Model: \_\_\_\_\_

Caliber: \_\_\_\_\_

Serial No. : \_\_\_\_\_

Purchased From (Dealer): \_\_\_\_\_

Dealer's Stamp: \_\_\_\_\_

Dealer's Address: \_\_\_\_\_

Date of Purchase: \_\_\_\_\_

Signature of Owner: \_\_\_\_\_



For more information please visit:  
[www.bularmory.com](http://www.bularmory.com)